



Thank you for purchasing this ALPHA COMPETITION product for your car!

Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached by the following email:

support@alpha-competition.com

GENERAL MODIFICATION NOTE

Modifications to any vehicle can change the handling and performance. As with any vehicle extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seatbelts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive a vehicle safely may result in serious injury or death. Do not drive a vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your country.

Consult the owner's manual, service manual, instructions accompanying these products, and local laws before purchasing and installing these modifications.

You are responsible for the legality and safety of the vehicle you modify using these components!



ALPHA COMPETITION Noise pipe delete plug

Installation instructions



img 1

1. Remove the hose clamp of noise pipe upper connector on the firewall (img.1)



2. Remove the upfront noise pipe bracket screw (can be Torx or Star)



3. Loosen the noise pipe lower slip in clamp and remove the T10 bolt on the lower bracket (img.3)



4. Unfold the MAF sensor wire holder (img.4) and gently remove the noise pipe

img 4



5. You can now install the Alpha Competition silicone plug using the supplied clamp. Do not over-tighten



6. Make sure everything is clean and back to standard position before starting the engine