



**Thank you for purchasing this ALPHA COMPETITION product for your car!**

Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached by the following email:

[support@alpha-competition.com](mailto:support@alpha-competition.com)

### **GENERAL MODIFICATION NOTE**

Modifications to any vehicle can change the handling and performance. As with any vehicle extreme care must be used to prevent loss of control or roll-over during sharp turns or abrupt maneuvers. Always wear seatbelts, and drive safely, recognizing that reduced speeds and specialized driving techniques may be required. Failure to drive a vehicle safely may result in serious injury or death. Do not drive a vehicle unless you are familiar with its unique handling characteristics and are confident of your ability to maintain control under all driving conditions. Some modifications (and combinations of modifications) are not recommended and may not be permitted in your country.

Consult the owner's manual, service manual, instructions accompanying these products, and local laws before purchasing and installing these modifications.

**You are responsible for the legality and safety of the vehicle you modify using these components!**



## **BRAKE COOLING GUIDES - Install Instructions -**



img 1

### **Supplied parts**

- > Alpha Air Diffusers x2
- > Alpha Diffusers Brackets x2
- > Screws x8 (2+1+1)
- > Washers x6
- > Spacer x2



img 2

### **Step 1**

**Using Allen, install the air diffusers on the mounting brackets**



img 3

**Step 2**  
**Prepare washer, bolt and spacer  
as shown on img.3**

**The spacer takes place on the  
mounting bracket as shown on  
img.4**



img 4

**Step 3**  
**Using the OEM hole on the front  
lower arm (img.5), install the  
Alpha Competition brake  
cooling guides**



img 5

**Step 4**  
**Using the bolt and washer start  
threading by hand the bolt in  
the spacer (img.6). Tighten  
gently then**



img 6

**Step 5**  
**Repeat the process for the  
other side and you're done !**

**- Congratulations -**



img 7