

# Instructions

## Rear Swaybar

**N.B:** This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

### Install Guide

**Application:** Renault Megane 2008-2016

**Contents:** 1x 18mm adjustable swaybar  
2x mounting brackets  
14x button-head bolts  
14x nyloc nuts  
6x washers

1. Raise vehicle evenly and safely support.
  2. Using a Jack, support rear beam under the spring platform.
  3. Proceed to remove the lower shock bolts. Slowly lower the Beam - and remove the rear springs and spring pad.
  4. Using supplied nuts, bolts and washers, bolt up the mounting brackets - note these are LH/RH. Do not tighten until swaybar is also bolted up. Refer image below.
  5. Bolt up swaybar to brackets with supplied nuts and bolts.
- Note - there are 4 supplied bolts/nuts per side for mounting. To adjust swaybar rate - remove the most forward bolt/nut - this will soften the swaybar rate.**
6. Tighten all bolts and re-fit spring pads and springs - bolt up shock mount.
  7. Road test - re-check bolts after initial 100kms travelled.



**LH bracket shown**

Note 4 mounting holes per side.  
Remove the front bolt/nut to  
reduce swaybar rate

A minimum of 3 bolts/nuts to  
be used for fitment.

**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.